
# Yealink

**UH48**USB Wired Headset



Quick Start Guide


### 1 Package List




**Note**: We recommend that you use the included accessories, and other accessories may compatibility issues that prevent them from working properly.

### 2 Connection

Plug the headset into either a USB-A/USB-C port on your computer, depending on the US variant of the headset.




### 3 Overview




## 4 Busylight Control

- Na Yealink USB Connect



### 5 Calls & Music



Play/pause music

Press once

## **6** Sound Control



Press once

 Switch among Noise Canceling/ Ambient Sound/Off

Hold for 2 sec • Active the Immersive Mode

#### Note:

- You can set the level of noise cancellation on Yealink USB Connect (desktop client) or Connect (mobile app).
- If you are in Noise Canceling mode, you might not hear the ambient sound. It depends ambient conditions and the type or volume of audio playback.
- Do not use the headset in places where the inability to hear ambient sounds would be gerous.

### 7 Replace Ear Cushions


Align the new cushion with the headset base and press fi rmly together.



**Note**: The replaceable ear cushions need to be purchased separately.

### 8 Software

You can update or manage your Yealink headsets through the Yealink USB Connect.



Download it from the Yealink website https://www.yealink.com/product/yuc.

**Note**: It needs to be used with Yealink USB Connect of version 0.34.x.x or higher.

**Note:** UH48 supports Yealink T27G/T4xS/T4xU/T53/T5xW/T58/VP59 through t USB connection. To have a better experience, the phone fi rmware is recommed to be v86 (xx.86.x.xx) or higher. You can fi nd more detail in the "Yealink set Compatibility Guide" from the Yealink support website.

If your headset needs warranty service, the process is quick and easy. Please to <a href="https://ticket.yealink.com/page/headset/warranty-service.html">https://ticket.yealink.com/page/headset/warranty-service.html</a> and submit RMA Claim to Yealink

5

#### Regulatory Notices

#### Operating Ambient Temperatures Operating temperature: +32 to 113°F (0 to 45°C)

- Relative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to +158°F (-30 to +70°C)

Warranty
Our product warranty is limited only to the unit itself, when used normal accordance with the operating instructions and the system environment are not liable for damage or loss resulting from the use of this product, c arising from the use of this product; we are not liable for financial damage profits, claims from third parties, etc., arising from the use of this produi

#### DC symbol

=== is the DC voltage symbol.

Restriction of Hazardous Substances Directive (RoHS) to use in the operating temperature range. ments of compliance can be obtained by contacting support@yealink.com

Safety Instructions
Save these instructions. Read these safety instructions before Save dust, etc., may be in the port.
1. Clean the port. The following basic safety precautions should always be followed to reduce risk

- fully and observe the situation during operation.

   During the process of storage, transportation, and operation, pleased that may cause undesired operation. Any changes or modifications not expression that may cause undesired operation. Any changes or modifications not expression to the process of the p always keep the device dry and clean, avoid collision and crash.
- discrepancy, please contact the appointed maintenance center for repair
- Legal rights of others should be respected as well.

- The marking information is located at the exterior of the bottom Place the device at a well-ventilated place. Do not expose the device equipment does cause harmful interference to radio or television recept
- under direct sunlight. Keep the device dry and free of dusts.
- Keep the device dry and free of dusts.
   Do not place the device on or near any inflammable or fire-vulner and —Reorient or relocate the receiving antenna
- object, such as rubber-made materials.

   Keep the device away from any heat source or bare fire, such as a lagrease the separation between the equipment and receiver.

  —Connect the equipment into an outlet on a circuit different from that to with
- dle or an electric heater
- Operating Requirements
  Operating Requirements
  - dental swallowing
  - Please use the accessories provided or authorized by the manufa
  - The power supply of the device shall meet the requirements of the sepul warning: The power supply of the device shall meet the requirements of the hours of the device complies with Innovation, Science and Economic Development voltage of the device. Please use the provided surge protection politics device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following
  - socket only completely dry.
  - Do not spill liquid of any kind on the product or use the equipment ation of the device.
  - During a thunderstorm, stop using the device and disconnect it from the suivantes: (1) l'appareil ne dot pas produce brouillage, et (2) the power supply. Unplug the power plug and the Asymmetric Digital
  - liahtnina strike.

  - power supply and unplug the power plug. When there is smoke emitted from the device, or some abnormal
  - or smell, disconnect the device from the power supply, and unpluding sairement protégées des indiscrétions.
  - Do not insert any object into equipment slots that is not part of the
  - uct or auxiliary product. · Before connecting a cable, connect the grounding cable of the device
  - Before connecting a cable, connect trie grounding cable until you disconnect a**contact information**First. Do not disconnect the grounding cable until you disconnect a**contact information**FALINK NETWORK ECHNOLOGY CO.,LTD.

Notices of Cleaning and anti-static cloth to clean the device.

430104002614

#### ENVIRONMENTAL RECYCLING



it should be taken to a special waste disposal center and treated separately to general urban waste

The unit cannot supply power to continue

The usage environment is out of operating temperature range.

ne cable between the unit and the Yealink device is connected incorrectly. Connect the cable correctly.

Contact your dealer or authorized service facility for any further questions.

Office electrical shock, and other personal injury.

General Requirement

Before you install and use the device, read the safety instructions by the complies with part 15 of the FCC Rules. Operation is subject to the Before you install and use the device, read the safety instructions by the complies with part 15 of the FCC Rules. Operation is subject to the Before you install and use the device, read the safety instructions by the proportion of the Before You install and use the device of the Before You instruction of the PCC Rules. Operation is subject to the Before You instruction of the PCC Rules. Operation is subject to the Before You instruction of the PCC Rules. Operation is subject to the Before You instruction of the PCC Rules. Operation is subject to the Before You instruction of the PCC Rules. Operation is subject to the PCC Rules. Operation is subject to the Before You instruction of the PCC Rules. Operation is subject to the PCC

 Please attempt not to dismantle the device by yourself. In case of approved by the party responsible for compliance could void the user's authorized the appropriate the Note: This equipment has been tested and found to comply with the limits for

repair.

• Please refer to the relevant laws and statutes while using the devite. Please refer to the relevant laws and statutes while using the devite. Please refer to the relevant laws and statutes while using the devite. The representation of the responsibility of early representations against the respective of th in a residential installation. This equipment generates, uses and can radiate

Environmental Requirements

Environmental Requirements

By this equipment is not intended ratio requency energy and, if not installed and used in accordance in the property of the property o there is no guarantee that interference will not occur in a particular installati

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help

 Do not let a child operate the device without guidance.
 Do not let a child play with the device or any accessory in case-of the equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. transmitter must not be co-located or operating in conjunction with any

other antenna or transmitter.

Before plugging or unplugging any cable, make sure that your hands accept any interference, including interference that may cause undesigned.

Do not spili liquio or any kind on the product or use the equipment mean water, for example, near a bathtub, washbowl, kitchen sink, wet base presentapparellestconforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux

Subscriber Line (ADSL) twisted pair (the radio frequency cable) to Minullageest susceptible d'encompromettre le fonctionnement.

Subscriber Line (ADSL) twisted pair (the radio frequency cable) to Minullageest susceptible d'encompromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003 If the device is left unused for a rather long time, disconnect it frocetappareilnumérique de la classe B estconformeà la norme NMB-003 du Canada.

noiscommunications effectuées au moyen de cetappareil ne sont pas

or small, disconnect the device from the power supply, and unpluging the power plug immediately. Contact the specified maintenance center ribs device meets the applicable Innovation, Science and Economic power plug immediately. Contact the specified maintenance center ribs device meets the applicable Innovation, Science and Economic Development Canada technical specifications. / Ce produit répond à la

innovation, des scienceset de Développement économique Canada es développement es de la complexitation es développement es de la complexitation es développement es de la complexitation es de la

No.666 Hu'an Rd, Huli District Xiamen City, Fujian, P.R. China YEALINK (EUROPE) NETWORK TECHNOLOGY B.V. Sir Winston Churchillin 299 k, 2288DC Rijswijk YEALINK (USA) NETWORK TECHNOLOGY CO., LTD 999 Peachtree Street Suite 2300, Fulton, Atlanta, GA, 30309, USA Made in China

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD. Web: www.yealink.com

Copyright@2024 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD. All rights reserved.